

Easy, Quick, Durable!

Drills into Porcelain, Ceramic, and other Hard to Drill Materials.



How to use



①Expand water tank by pulling the handle portion towards drill.



②Fill with clean water.

NOTE

Use only our standard bottle.(ASWB)



③Flip the release lever switch towards the arrow to activate the water tank.



Start drilling.
 NOTE
 Maintain between 1000
 -3000 rpm while drilling to ensure water is released.

Characteristics

- Built-in water tank self feeds water.
- Quick change body.
- Replaceable cutter.
- One shank fits all sizes.

For use in

- Porcelain
- Ceramic
- Granite

Specifications

- Shank: 1/4" Hex
- Dia: 5/32" 3/8"
- Max Drilling Depth: 1" 3/8"
- Optimum RPM: 1000 3000 rpm



http://www.miyanagaamerica.com/

AQUASHOT (Diamond Tip)



Size Table

_						1				
Diameter		AQUASHOT Set		Cutter Only		Body Only		Shank Only		
mm	inch	Part No.	List Price	Part No.	List Price	Part No.	List Price	Part No.	List Price	
4.0	5/32	AS532STU	\$199.00	DMU532C	\$20.96	AS040B	\$30.00			
5.0	3/16	AS316STU	\$199.00	DMU316C	\$20.96	AS050B	\$30.00			
6.5	1/4	AS14STU	\$199.00	DMU14C	\$24.90	AS060B	\$30.00	ASSKJDU	\$157.00	
8.0	5/16	AS516STU	\$215.00	DMU516C	\$41.80	AS080B	\$30.00			
10.0	3/8	AS38STU	\$229.00	DMU38C	\$45.82	AS100B	\$33.50			

^{*}Water Bottle included in sets.

Accessories

Part No.	List Price	Discription			
ASWB	\$3.60	Water Bottle			
SJP038	\$49.80	Dust Collecting Pad			
DDP	\$85.12	Dressing Plate			
DDPS	\$29.00	Dressing Plate-S			
DMPE1	\$7.84	Plug Ejector			
ITPG	\$60.16	Positioning Guide			
PP	\$10.00	Positioning Plate			



ASWB



SJP038



ITPG



DMPE1

DDP

PP

Kits

	Cutter & Body					Shank	Accessories				
Part No.	5/32	3/16	1/4	5/16	3/8	ASSKJDU	ITPG	DMPE1	DDPS	ASWB	List Price
ASKIT1				•							\$580.00
ASKIT2											\$450.00
ASKIT3											\$324.00
ASKIT4											\$324.00
ASKIT5											\$328.00
ASKIT6				•							\$346.00
ASKIT7							•			•	\$354.00

 \frak{MAII} kits come in custom carring case.





*Case only \$30.00

*Check out the video instruction on line.



http://youtu.be/mzxoEbCD7PA



MIYANAGA America Corp.

1010 W. Republic Dr. Unit 1 Addison, Illinois 60101 USA Tel:(630)359-5795 Fax:(630)359-5806 http://www.miyanagaamerica.com/







MIYANAGA CO.,LTD

Registered office and Factory-Japan Representative Office-Europe